

Magdrive

Linear Actuator



Read this manual before installing, operating or maintaining this actuator. Failure to follow safety precautions and instructions could cause actuator failure and result in serious injury, death or property damage.



® SKF and Magnetic are registered trademarks of the SKF Group.

© SKF 2005

The contents of this publication are the copyright of the publisher and may not be reproduced (even extracts) unless prior written permission is granted.

Every care has been taken to ensure the accuracy of the information contained in this publication but no liability can be accepted for any loss or damage whether direct, indirect or consequential arising out of the use of the information contained herein.



Table of Contents

	Basic Principles	4
1	Introduction	4
	Operating instructions	4
	Organizational Measures	5
	Conventions	6
2	Safety	8
	Safety Program	8
	Other hazards	10
3	Structure and Function	13
	Construction	13
	Function	14
	Options and accessories	15
	Normal Operation	16
4	Normal Operation	16
	Normal Operation	16
	Special Operations	18
5	Installation and Initial Start-Up	18
	Preparation	18
	Installation and Connections	19
	Initial Start-Up	21
6	Maintenance, Clearing malfunctions, Repairs	22
	Maintenance	22
	Malfunctions	23
	Repair	26
7	Removing from service, dismantling and disposal	27
	Shutting down	27
	Dismantling	27
	Storage	27
	Disposal	28
	Appendix	29
8	Appendix	29
	Technical data	29
	Plans and diagrams	29
	Standards applied	30

Basic Principles

The following chapters are part of the basic principles:

- 1. *Introduction*, page 4
- 2. *Safety*, page 8
- 3. *Structure and Function*, page 13

1. Introduction

This chapter contains information on the organization and structure of the operating instructions. It makes the instruction manual easier to handle and enables quick access to the desired information.

Operating instructions

Magnetic Elektromotoren AG manufactures state of the art electric motors.

The purpose of these operating instructions is to introduce you, as the user and the entity doing the further processing, to correct utilization and safe use.

For this goal to be achieved, it is essential that you very carefully read the chapter on *safety* (2. *Safety*, page 8) and follow the instructions in this manual.

Validity

The instructions in this manual refer to the linear actuator MAGDRIVE™ with the following identification:

- Manufacturer: Magnetic Elektromotoren AG, Liestal
- Product name: Linear actuator MAGDRIVE™
- Type designation: MD
- Year of manufacture: from 2005
- CE Mark: according to technical documentation
- Serial number: from production start

Target audience and obligation to read

These operating instructions are intended for technical personnel and authorized users who use the linear actuator MAGDRIVE™ in their products and work with it. The operating authority determines who is authorized as a user.

We distinguish between different user groups, as the requirements on the users vary, depending on the activity they perform.

Please note: You can find definitions of user groups along with their corresponding requirements in the chapter on safety (2. *Safety*, page 8). You can assume one or more of these user groups provided you meet the applicable requirements.

Introduction

The organization and implementation of the operating instructions takes into account the different user groups.

Summary of Contents

The operating instructions serve as a reference work. The information therein is organized into four task- and theme-related parts:

<i>Basic Principles</i>	The <i>Basic Principles</i> section gives the basic knowledge that every user should have.
<i>Normal Operation</i>	The <i>Normal Operation</i> section contains information needed for operating the product under normal conditions, i.e. uninterrupted operation for use according to its intended application.
<i>Special Operations</i>	The <i>Special Operations</i> section describes all jobs deviating from normal operation, such as installation, initial start-up, maintenance, fixing faults and carrying out repairs.
<i>Appendix</i>	The <i>Appendix</i> contains information that the user has to be able to access at any time. This includes information on using the operating instructions (indexes) as well as data concerning the product itself (technical data).

Aids for accessing information

This manual has access aids that make it easier for you to quickly access the desired information:

- You can most easily find all information on a given topic in the *Table of Contents*, as a result of the task and theme-related organization of the operating instructions.
- Information on a specific activity or a special topic can be found most quickly through the *Index*.
- Within the chapters of the operating instructions, you can orient yourself with the help of the margin notes.

Organizational Measures

If you have any questions that cannot be answered through these operating instructions, contact the manufacturer directly.

Location of the Operating Instructions

The operating instructions can only benefit you if you have them available at all times. For this reason, always keep the operating instructions where the equipment is being used.

Manufacturer Address

Magnetic Elektromotoren AG
Oristalstrasse 97
CH-4410 Liestal
Tel.: +41 / 61 / 925 41 11
Fax: +41 / 61 / 921 37 04
E-mail: actuators.switzerland@skf.com

Contact Address

Your local SKF representative.


Conventions


In this manual we use a few abbreviations and markings to label sections of text or notes. In the following sections you will find these conventions explained.

Warnings and Usage Hints

Please note the meaning of the following warnings and usage hints:

Please note: indicates usage information that helps the user to use the product correctly and efficiently or to understand the properties of the product.

	⚠ CAUTION
	Caution: warning to inform the user of hazards that remain due to the incomplete effectiveness of protective measures for property damage or personal injury; points out any special training and personal protective equipment that may be required.

	⚠ WARNING
	Warning: warning of irreparable property damage or personal injury that remain based on hazard analysis. With reference to protective measures and any special training and personal protective equipment that may be required.

Text markings

Position Numbers and References

Position numbers

We number diagram parts clockwise in serial order and unambiguously.

Cross-references to text passages

Cross-references to chapters or diagrams are given in parentheses. They contain the corresponding chapter or diagram number.

Introduction

Type plate

Find the following symbols on the type plate:



Please observe the accompanying documents



Electrical and electronic appliances have to be collected separately and must not be disposed of with household waste

2. Safety

This chapter is intended for all users of the MAGDRIVE™ linear actuator. It contains information on its safe use and optimal utilization.

Safety Program

The safety program from Magnetic Elektromotoren AG spells out who is entitled to use it and the responsibility of individual users.

The MAGDRIVE™ was designed and built in accordance with the latest technical standards and accepted safety rules.

CE-conformity is documented with the technical documentation.

Purpose of the MAGDRIVE™

The linear actuator MAGDRIVE™ has been designed and built to be operated in accordance with its intended use. If you use the MAGDRIVE™ for any use other than that cited, the manufacturer cannot be held responsible for damage resulting from this.

The MAGDRIVE™ has been designed for interior applications in the industrial, medical and building services engineering sectors.

Intended Use

The intended use of the MAGDRIVE™ is:

- MD22/24: dynamically centered pressured lifting
- MD23/25: dynamically centered pressured or tension-stressed lifting

Please note: For the operations data, please see the *Appendix* of this operating manual (see *Equipment and operating data*, page 29) and associated datasheets.

Unauthorized Use

Any use other than the *intended use* without the manufacturer's written agreement or operation beyond the technical limits is considered unauthorized.

You can find the technical operating limits in the appendix (*Technical data*, page 29) of this manual, the associated datasheets and on the type plate of the MAGDRIVE™.

Please note: Any unauthorized use of the MAGDRIVE™ can cause personal injury and property damage. Always adhere to the instructions of this manual.

Safety

User groups

To ensure safety, we place requirements on the users of the MAGDRIVE™ that must be adhered to under all circumstances. Only persons who meet the requirements are entitled to use the MAGDRIVE™.

We refer to all persons who operate, use, commission the linear actuator, process it further or pass it on for further processing as user groups. As the requirements of these user groups strongly depend on their role, we distinguish between the following user groups:

<i>Operating Authority</i>	The operating authority is the contractual partner of the person doing the further processing or the reseller. They can impose legal conditions on the operating authority when purchasing the linear actuator. The operating authority ensures that the user is instructed in the authorized use of the equipment.
<i>Processor</i>	The processor is the contractual partner of the reseller or the manufacturer. He assembles the linear actuator into a complete device. He is authorized by the manufacturer to use the linear actuator MAGDRIVE™ in accordance with the regulations and has the necessary expert knowledge.
<i>Technician</i>	The technician has the professional technical training to utilize the linear actuator MAGDRIVE™ according to its authorized use. Apart from the chapter on <i>Safety</i> , he is also familiar with the chapter on <i>Special operating modes</i> . He will find the required technical data in the <i>Appendix</i> .
<i>Reseller</i>	The reseller forwards the machine.
<i>Operator</i>	Any other person who uses the MAGDRIVE™ is defined as an operator. The operator must have read the <i>Safety</i> chapter in this manual before using the machine. Moreover, he must be instructed about <i>normal operation</i> by the <i>operating authority</i> .

Types of Operation

<i>intermittent</i>	The linear actuator MAGDRIVE™ is only to be used for intermittent operation (refer to <i>Technical data</i> , page 29 or associated datasheets).
---------------------	--

Danger Zones

We differentiate between two danger zones that must be observed, depending on the user role.

<i>Persons</i>	The danger zone covering <i>persons</i> also includes, in addition to the actual user, third persons (other personnel, visitors, patients etc.). In case of injury, the operating authority is liable.
<i>Device</i>	The danger zone <i>device</i> comes under the <i>Processor</i> and <i>Technician</i> user groups and covers the linear actuator MAGDRIVE™ and any elements that have been attached.

Areas of Responsibility

Different areas of responsibility, corresponding to the different user groups, arise.

Safety

- Operating Authority* The operating authority bears the responsibility for the danger zone covering *persons* and ensures that only authorized and trained users work with the MAGDRIVE™. He or she is responsible for the following:
- Identifying the persons who are allowed to use the MAGDRIVE™ (authorized persons)
 - Instructing the user groups
 - Complying with all relevant legal conditions and regulations
- Please note: The *operating authority* may only authorize persons to use the MAGDRIVE™ who meet the requirements for the user groups.**
- Processor* The processor is responsible for the following:
- Forwarding a CE-conformant operating manual for the device in which the linear actuator MAGDRIVE™ is installed
 - Adherence to the safety regulations in accordance with this operating manual
- Reseller* The reseller is responsible for the following:
- Forwarding this operating manual and the linear actuator MAGDRIVE™ to the processor or
 - forwarding a CE-conformant operating manual and the device in which the linear actuator MAGDRIVE™ is installed to the operating authority
- Technician* The technician is responsible for the following:
- Observing the manufacturer's instructions and the safe set-up of interfaces with other equipment.
 - Installation and use of the MAGDRIVE™ in accordance with its intended use
 - Installation of optional modules and connecting cables
- Operator* The operator ensures that nobody will be endangered when the MAGDRIVE™ is running. He or she is, in particular, responsible for:
- Operating the MAGDRIVE™ in normal operating conditions
 - Immediate and appropriate reaction to malfunctions

General safety notice

The linear actuator is suitable **for internal use only** and must not be exposed to weathering, strong UV radiation or corrosive or explosive atmospheric media, or other aggressive media (see Appendix *Ambient conditions*, page 29 and associated datasheets).


Other hazards


The manufacturer has constructively, and with protective measures, minimized the effects of existing residual hazards. Pay attention to the residual hazards and the potential countermeasures given in the following chapters.


Safety


Residual hazards to people, objects and property

Pay attention to the following residual hazards and the possible countermeasures for dealing with them MAGDRIVE™:


	⚠ WARNING
	<p>Risk of hand injuries when the motor is running due to clamping on the push tube's fork head. If the fork head is not installed in the device there is a turning movement. Do not let any object or person come into contact with the push tube's fork head while the motor is running. Hold the MAGDRIVE™ only by the tube casing.</p>

	⚠ WARNING
	<p>Warning for risk of crushing and damage to the MAGDRIVE™ caused by static and dynamic overloading of the linear actuator. When driving against fixed objects the impact of the force can cause personal injury. Make sure that there are no persons or fixed objects present in the danger zone during the stroke.</p> <ul style="list-style-type: none">• Note the maximum permissible operating data in the Appendix (see <i>Equipment and operating data</i>, page 29) or the associated datasheets• Note the type plate of the linear actuator

	⚠ WARNING
	<p>Warning of side-acting forces. Excessive side-acting forces destroy the drive and pose a danger to persons. During the stroke, do not manipulate any of the elements that are connected to the MAGDRIVE™.</p>

	⚠ CAUTION
	<p>Please note that the MAGDRIVE™ can be damaged by water or other fluids. MAGDRIVE™ is only protected to IPX0 or, as an option, IPX4S (sprayed water). In any case, the MAGDRIVE™ must be prevented from being exposed to sprayed water when moving in or out.</p>

Safety

⚠ CAUTION	
	<p>Be aware that the MAGDRIVE™ can be destroyed by overheating. The MAGDRIVE™ is designed for intermittent use. If used improperly >10% ED the linear actuator can be destroyed and there may be damage to property. Adhere strictly to operating and standstill times.</p> <ul style="list-style-type: none">• Use a control unit with an integrated thermo-switch.• Please refer to the appendix (refer to <i>Equipment and operating data</i>, page 29) or associated datasheets.

3. Structure and Function

This chapter is intended for all users of the MAGDRIVE™. It shows its construction and explains its function.

Construction

The following figure will give you an overview of the linear actuator.

Overall view MAGDRIVE™




Fig. 3-1 Overall view MAGDRIVE™

- 1 Hinge head on the engine casing
- 2 Tube casing / Motor casing
- 3 Push tube
- 4 Fork head of the push tube
- 5 Direction of movement when moving out
- 6 Direction of movement when moving in

Operating elements

The Magnetic operating elements are available as accessories for the MAGDRIVE™ and the Magnetic control unit. If you have any questions, please consult the corresponding operating manuals for these devices.

Structure and Function

Function

A description of its function allows you to understand what the linear actuator and its individual parts do.

Functional principles

The operating principle of the linear actuator MAGDRIVE™ **MD22/24** is based on pressure only (tension stress is only permitted for transport purposes and limited in line with operating data (refer to *Equipment and operating data*, page 29 and/or associated datasheets).

The operating principle of the linear actuator MAGDRIVE™ **MD23/25** is based on tension stress or pressure. MD23/25 must not be operated with alternating load (refer to *Equipment and operating data*, page 29 and/or associated datasheets).

The built-in brake decelerates the movement or holds the position at a standstill (refer to *Fig. 3-1, page 13, Pos. 5 and 6*). No lateral pressure or turning movement may be caused.

The linear drive MAGDRIVE™ must be equipped with a Magnetic control unit and operating unit.

<i>Tube casing / motor casing (2)</i>	The tube casing / motor casing as the load-bearing component with an integrated engine, gear and linear unit. The power cable (motor cable with low-voltage plug) is firmly installed in the tube casing / motor housing. At the lower end of the tube casing a hinge head is fixed; this is used to move the actuator to the application on one side.
<i>Motor unit</i>	The permanent magnet motor is a 24 V DC motor that drives the planetary gear via the motor shaft. The speed of the thrust depends on the load.
<i>Drives</i>	The planetary gear is driven directly by the motor shaft which moves a worm gear.
<i>Linear unit</i>	The linear unit / the push tube is integrated into the tube casing / motor casing. The worm gear converts the gear's turning movement via the spindle nut into a linear movement. If the spindle nut breaks an integrated safety nut protects the push tube from also breaking. An in and out movement is executed via the push tube. The push tube is surrounded by the tube casing / motor casing (2) and protected by it. The base of the push tube is connected with the worm gear via the spindle nut, at the top is the fork head (4) of the push tube (3).
<i>Thermo-switch</i>	The linear drive MAGDRIVE™ does not have any thermal protection and can be damaged by overheating. For this reason a control unit with an integrated thermo-switch must be used. This switches the MAGDRIVE™ off in an emergency. The linear actuator must not be operated until the drive temperature has fallen below the switching threshold.
<i>Brake</i>	The brake is attached to the spindle, its purpose is to decelerate the worm gear and support the self locking.
<i>End switch</i>	The linear actuator is equipped with internal end switches that switch off the linear actuator at the end positions. If the end switches fail the linear actuator moves to one of the two buffers attached to each side if a serious error occurs, blocks and releases the current cut off integrated into the control unit or removes the power from the linear actuator.

Structure and Function

Options and accessories

Options

Options can be recognized from the type designation on the type plate.

- | | |
|--|--|
| <i>Emergency lowering</i> | For applications where lowering takes place mechanically in an emergency it is possible to equip the linear actuator with an optional emergency lowering device. Then it is possible, if for example the power fails or there are drive errors, to lower the application manually (refer also to the <i>Emergency Shutdown</i> , page 17) section. |
| <i>Electrical anti pinching protection</i> | The <i>electrical anti pinching protection</i> is an electrical switch that switches the linear actuator off when moving in (6) if the stroke is hindered by an object or body part. This protection does not work when moving out (5). |
| <i>Encoder</i> | With the Hall sensor, the <i>encoder</i> picks up impulses from a magnetic disk located on the motor shaft. |
| <i>IPX4S</i> | The linear actuator MAGDRIVE™ may be supplied as an option with protection class <i>IPX4S</i> . This protects the MAGDRIVE™ against sprayed water (refer to 4. <i>Normal Operation</i> , page 16). |

Accessories

- | | |
|---------------------------|---|
| <i>Control unit</i> | The linear actuator MAGDRIVE™ requires a Magnetic control unit to power the motor. Only use Magnetic control units. |
| <i>Operating elements</i> | The linear actuator MAGDRIVE™ can be operated remotely by a Magnetic operating element on the control unit. Only use Magnetic operating elements. |

Important: Magnetic Elektromotoren AG will not accept liability for any damage caused if the linear actuator MAGDRIVE™ is not used with a suitable Magnetic control unit / operating element.

Normal Operation

4. Normal Operation

This chapter is directed at the user groups *operator* and *operating authority*. It provides all the information required for the safe and smooth operation of the linear actuator under normal operating conditions.


Normal Operation


In normal operation the linear actuator lifts or lowers elements which are connected to the MAGDRIVE™ via the fork head and hinge head.

Preconditions for operation


A Magnetic control unit controls the MAGDRIVE™ (refer to *Accessories*, page 15).


Switch on linear actuator

⚠ WARNING	
	<p>Warning for risk of crushing and damage to the MAGDRIVE™ caused by static and dynamic overloading of the linear actuator. When driving against fixed objects the impact of the force can cause personal injury. Make sure that there are no persons or fixed objects present in the danger zone during the stroke.</p> <ul style="list-style-type: none">• Note the maximum permissible operating data in the Appendix (see <i>Equipment and operating data</i>, page 29) and associated datasheets• Note the type plate of the linear actuator

⚠ WARNING	
	<p>Warning of side-acting forces. Excessive side-acting forces destroy the drive and pose a danger to persons. During the stroke, do not manipulate any of the elements that are connected to the MAGDRIVE™.</p>

Normal Operation

	⚠ CAUTION
	<p>Be aware that the MAGDRIVE™ can be destroyed by overheating. The MAGDRIVE™ is designed for intermittent use. If used improperly >10% ED the linear actuator can be destroyed and there may be damage to property. Adhere strictly to operating and standstill times.</p> <ul style="list-style-type: none">• Use a control unit with an integrated thermo-switch.• Please refer to the appendix (refer to <i>Equipment and operating data</i>, page 29) or associated datasheets.

	⚠ CAUTION
	<p>Please note that the MAGDRIVE™ can be damaged by water or other fluids. MAGDRIVE™ is only protected to IPX0 or, as an option, IPX4S (sprayed water). In any case, the MAGDRIVE™ must be prevented from being exposed to sprayed water when moving in or out.</p>

The Magnetic control unit must be connected to mains electricity. It is operated by a Magnetic operating element (see *Accessories*, page 15).

Emergency lowering

For applications with emergency lowering in special cases, such as power failure or operational defects, it may be desirable to lower the load manually.

Please note: Excessive use of effort or an independent downward movement indicate a damaged actuator. The MAGDRIVE™ must not be run any more. Immediately inform the manufacturer that performs the inspection.

Emergency Shutdown

- 1 Pull out the plug of the cable that connects the linear actuator to the control unit.

Please note: The MAGDRIVE™ does not have an on / off switch and must be separated from the power supply to the control unit. Only this measure will de-energize the MAGDRIVE™.

Patient lifters

An emergency off switch is essential for patient lifters.

Please note: The emergency shut-off switch must be fitted by the executor.

Special Operations

The following chapters are part of the special operations:

- 5. *Installation and Initial Start-Up*, page 18
- 6. *Maintenance, Clearing malfunctions, Repairs*, page 22
- 7. *Removing from service, dismantling and disposal*, page 27

5. Installation and Initial Start-Up

This chapter is intended for *technicians and those doing the further processing*. It provides all the information that you need to assemble, connect and start up the linear actuator MAGDRIVE™.

Preparation

Good preparation is part of efficient installation and start-up. This includes, among other things, deciding on a location and having an energy source ready.

Transport

Please note: The linear actuator must be examined for damage on delivery. Any transit damage is to be notified to the carrier and the manufacturer immediately and in writing.

The linear actuator MAGDRIVE™ is delivered as a unit in a box or on pallets. Instruct a carrier to ship the linear actuator.

Return to the manufacturer

Prepare the linear actuator for transport as follows:

- 1 Dismantle the linear actuator (refer to *Dismantling*, page 27)
- 2 Pack the linear actuator carefully.

Please note: the storage conditions also apply to the transport (refer to *Storage*, page 27). You can find important information on weight, dimensions etc. in the technical data in the appendix (*Technical data*, page 29) and the associated datasheets.

Check items in shipment

The linear actuator comprises:

- a complete actuator unit comprising drive, motor and linear unit
- a cable with a low-voltage plug

Installation and Initial Start-Up

Power supply

The linear actuator MAGDRIVE™ runs solely on electricity. Observe the connection values in the appendix of this manual (chapter *Equipment and operating data*, page 29) or the associated datasheets.

Installation and Connections

Installing the linear actuator MAGDRIVE™ on other elements involves taking into account special requirements of different applications.

The linear actuator MAGDRIVE™ is fixed to two elements via the fork head and hinge head.

The following sections show how to set up and align the linear actuator MAGDRIVE™, as well as the interfaces and connections.

Set-up and Adjustment

In setting up and aligning the linear actuator MAGDRIVE™ the following points must be observed.

Make sure that

- the fork head and hinge head and the application elements are connected with fastening bolts (only use fastening bolts! Screws and such like may **not** be used due to pre-tensioning, poor positioning or flexing).
- the acting force also works centrally on the push tube (lateral forces or those that exert a torque on the linear unit can destroy the linear actuator),
- the linear actuator is not obstructed in any way in the entire stroke area.
- the cables are not pinched or caught or subject to tension stress,
- you **never** loosen screws on the MAGDRIVE™ or try to open the linear drive MAGDRIVE™ (Magnetic Elektromotoren AG rejects all warranty claims if screws on the MAGDRIVE™ have been manipulated).


Interfaces and Connections

You can find the nominal values in the appendix (section *Technical data*, page 29) or associated datasheets. Check that all interfaces and connections have been mounted and/or connected correctly.

- Interfaces for the application fixed to the fork head and hinge head
- Connection to an appropriate control unit (refer to *Accessories*, page 15)
- Connection to an appropriate operating unit (refer to *Accessories*, page 15)

Installation and Initial Start-Up

Installation

	⚠ WARNING
	<p>Risk of hand injuries when the motor is running due to clamping on the push tube's fork head. If the fork head is not installed in the device there is a turning movement. Do not let any object or person come into contact with the push tube's fork head while the motor is running. Hold the MAGDRIVE™ only by the tube casing.</p>

Proceed as follows for installation:

- 1 Secure the elements that you want to connect the linear actuator to, so that you can place the MAGDRIVE™ between them.
- 2 Connect the fork head and the hinge head with each element of the application
- 3 Mount the elements on the fork head and on the hinge head with fastening bolts

Please note: Only use fastening bolts; screws and such like may not be used due to pre-tensioning, poor positioning or flexing. The fastening bolts are not supplied. The bore dimensions can be found in the *Plans and diagrams*, page 29 section or the associated datasheets. Please ensure that the connection cannot become loose unintentionally.

Please note: Neither lateral forces nor a torque may affect the linear actuator.

- 4 Connect the linear actuator MAGDRIVE™ with the matching control unit by connecting the plug with the motor output of the control unit.
- 5 Pull the low voltage plug out of the corresponding control unit.
- 6 Connect the corresponding operating element to the corresponding control unit (see relevant operating instructions).
- 7 Connect the corresponding control unit to the mains supply (see applicable operating instructions).

Now you can operate the linear drive in accordance with the relevant operating instructions of the corresponding control unit.

Third-party control units

All control units that have not been authorized by Magnetic Elektromotoren AG for MAGDRIVE™ are considered to be third-party devices. When using a third-party control unit Magnetic Elektromotoren AG does not accept liability for any damage incurred. The following list includes, without guaranteeing completeness, additional points that must be observed.


The third-party control unit must:

- have an over-current circuit breaker,
- the over-current circuit breaker must be deactivated for 250 ms when switched on,
- switch off the linear actuator if the power exceeds 8.5 A for 50 ms,
- prevent the maximum operating time from being exceeded.

Initial Start-Up

Perform the installation check before you start up the linear actuator for the first time MAGDRIVE™.

Installation Check

	⚠ WARNING
	<p>Warning for risk of crushing and damage to the MAGDRIVE™ caused by static and dynamic overloading of the linear actuator. When driving against fixed objects the impact of the force can cause personal injury. Make sure that there are no persons or fixed objects present in the danger zone during the stroke.</p> <ul style="list-style-type: none">• Note the maximum permissible operating data in the appendix (see <i>Equipment and operating data</i>, page 29) or the associated datasheets• Note the type plate of the linear actuator

Check the following points before the initial start-up:

- No lateral forces on the push tube
- No torque on the push tube
- Fixing bolts secured on the fork head and hinge head
- Entire stroke area not obstructed, so that the linear actuator cannot be driven onto a fixed object
- Electrical power supply secured via a Magnetic control unit (low-voltage plug correctly connected with Magnetic control unit)
- Magnetic operating element connected to the Magnetic control unit

Initial Start-Up

After the installation check has been completed, you can start up the linear actuator MAGDRIVE™: To do so, press the corresponding operating button of the Magnetic operating element.

6. Maintenance, Clearing malfunctions, Repairs

This chapter is intended for *technicians* and *those doing the further processing*. It provides you with all the information you need for maintaining, clearing malfunctions and carrying out repairs on the linear actuator MAGDRIVE™.


Maintenance

Maintenance includes all operations which keep the linear actuator fully functional. These operations include inspections, replacing consumables and cleaning.

Maintenance plan

The linear actuator MAGDRIVE™ is virtually maintenance-free for the full duration of its service life (you can find details on its service life in the appendix, *Equipment and operating data*, page 29). The connection cables and linear actuator have to be checked for wear and tear at regular intervals.

Cleaning

	⚠ CAUTION
	<p>Please note that the MAGDRIVE™ can be damaged by water or other fluids. MAGDRIVE™ is only protected to IPX0 or, as an option, IPX4S (sprayed water). In any case, the MAGDRIVE™ must be prevented from being exposed to sprayed water when moving in or out.</p>

Observe the following points when cleaning:

- Clean soiled parts immediately
- Use a damp cloth
- Wash water including added chemicals must be pH-neutral.
- Acidic or alkaline wash water can destroy metallic and plastic parts.

Medical area

- Hand-wash disinfection exclusively with *isopropyl alcohol*

Emergency lowering

For applications with emergency lowering, the following must also be observed:

- Disinfection and cleaning the emergency lowering mechanism only using *propyl-alcohol*
- The emergency lowering mechanism may not be treated with oil, grease or other lubricants
- If the emergency lowering does not work properly, inform the manufacturer of the application immediately

Please note: Other cleaners apart from those stated (e.g. high-pressure steam cleaners etc.) damage the linear actuator. Always contact the manufacturer if you want to use other cleaning agents.

Maintenance, Clearing malfunctions, Repairs

Malfunctions

Any faults occurring in the linear actuator MAGDRIVE™ may only be rectified by a technician authorized by the manufacturer. In this case the MAGDRIVE™ must be removed from service (see section *Shutting down*, page 27) and sent to Magnetic Elektromotoren AG (see section *Transport*, page 18).

In the following sections, you will find hints on how you can recognize, remedy or handle malfunctions.

Please note: In any case, immediately inform customer service (see *Manufacturer Address*, page 6) if the fault cannot be rectified on the basis of the following instructions.

Important: For reasons of safety the MAGDRIVE™ may not be opened and the screws on the linear actuator MAGDRIVE™ may not be manipulated. The warranty is made void by such intervention.

Recognizing malfunctions

Symptom 1: Linear actuator MAGDRIVE™ will not move

Hypothesis 1-A: No supply voltage or absence of plug contact

- 1 Insert the low-voltage plug of the MAGDRIVE™ into the Magnetic control unit
- 2 Plug the Magnetic control unit's mains cable into a mains socket.
- 3 Connect the operating element to the corresponding connection of the control unit.

Finding: MAGDRIVE™ Does it move now?

Yes. 4. *Normal Operation*, page 16
No *Hypothesis 1-B*

Hypothesis 1-B: Motor cable and/or the operating unit cable, and/or the mains cable of the control unit defective

- 1 Check the motor cable and/or the operating unit cable, and/or the mains cable of the control unit.

Finding: Motor cable and/or the operating unit cable, and/or the mains cable of the control unit damaged?

Yes. *Manufacturer Address*, page 6
No *Hypothesis 1-C*

Hypothesis 1-C: Obstacle is obstructing the MAGDRIVE™

Maintenance, Clearing malfunctions, Repairs

- 1 Remove all objects that impede the stroke.

Finding: MAGDRIVE™ Does it move now?

Yes..... 4. *Normal Operation*, page 16
No *Hypothesis 1-D*

Hypothesis 1-D: Wrong control unit

- 1 Check the type plate of the control unit.

Finding: Is the manufacturer of the control unit Magnetic Elektromotoren AG and is it approved for the MAGDRIVE™?

Yes..... *Hypothesis 1-E*
No *Replace control unit*

Hypothesis 1-E: Incorrect useful load

- 1 Check the type plate of the linear actuator.
- 2 Measure the static or dynamic load.

Finding: Has the useful load been exceeded (see *Technical data*, page 29 or associated data sheets)?

Yes..... *Manufacturer Address*, page 6
No *Hypothesis 1-F*

Hypothesis 1-F: Control unit defective

- 1 Carry out the troubleshooting procedure for the Magnetic control unit.

Finding: Is the Magnetic control unit faulty?

Yes..... *Replace control unit*
No *Hypothesis 1-G*

Hypothesis 1-G: Service life exceeded

Finding: Is the linear actuator MAGDRIVE™ older than 10 years or has it carried out more than 10,000 double strokes at 200 mm stroke length?

Yes..... *Manufacturer Address*, page 6
No *Hypothesis 1-H*

Hypothesis 1-H: The linear actuator cannot be made to move by any of the measures listed above

- 1 Contact the manufacturer immediately (*Manufacturer Address*, page 6).

Symptom 2: Linear actuator cannot be operated

Hypothesis 2-A: Magnetic operating element defective

Maintenance, Clearing malfunctions, Repairs

- 1 Check the type plate of the operating element.

Finding: Is the manufacturer of the operating elements Magnetic Elektromotoren AG and is it approved for the MAGDRIVE™?

Yes..... *Manufacturer Address, page 6*

No *Replace operating element*

Symptom 3: Load cannot be lifted

Hypothesis 3-A: Spindle nut defective

- 1 Remove all objects that impede the stroke.

- 2 Remove all loads on the elements.

Finding: Does the linear actuator move normally?

Yes..... *4. Normal Operation, page 16*

No *Manufacturer Address, page 6*

Symptom 4: Greatly reduced speed

Hypothesis 4-A: Motor, gears or spindle nut faulty

- 1 Remove all objects that impede the stroke.

- 2 Remove all loads on the elements.

Finding: Is the speed normal again?

Yes..... *4. Normal Operation, page 16*

No *Manufacturer Address, page 6*

Symptom 5: Greatly increased running noises

Hypothesis 5-A: Motor, gears or spindle nut faulty

- 1 Remove all objects that impede the stroke.

- 2 Remove all loads on the elements.

Finding: Still elevated running noises?

Yes..... *Manufacturer Address, page 6*

No *4. Normal Operation, page 16*

Symptom 6: Increased play between push tube and tube casing

Diagnosis 6-A: Sliding elements worn, immediately inform customer service (*Manufacturer Address, page 6*).

Maintenance, Clearing malfunctions, Repairs

Repair

The linear actuator MAGDRIVE™ may only be opened by the manufacturer. In any case, contact customer service (*Manufacturer Address*, page 6).

Emergency lowering

If excessive force is required for the turning movement or it is very easy to move under nominal load (i.e. independent lowering movement by linear actuator) the linear actuator may no longer be operated. The manufacturer must examine the linear actuator MAGDRIVE™. Immediately inform customer service (*Manufacturer Address*, page 6).

7. Removing from service, dismantling and disposal

This chapter is intended for *technicians* and *those doing the further processing*. It provides you with all the information needed to remove the linear actuator MAGDRIVE™ from service, dismantle it and dispose of it.

Shutting down

The linear actuator MAGDRIVE™ is to be removed from service in the following sequence:

- 1 De-energize the linear actuator by unplugging the mains plug of the control unit from the power outlet.
- 2 Secure the elements in such a way that there is no pulling or pushing force resting on the fork head and hinge head.
- 3 Loosen the lock that connects the low voltage plug of the MAGDRIVE™ with the Magnetic control unit.
- 4 Pull the low voltage plug out of the Magnetic control unit.

Afterwards you can dismantle or reinstall the MAGDRIVE™.

Dismantling

Before you start dismantling, put the linear actuator MAGDRIVE™ out of operation (see *Shutting down*, page 27). The linear actuator MAGDRIVE™ is to be dismantled in the following sequence:

- 1 Ensure that there is no pressure acting on the fork head and hinge head.
- 2 Loosen the fastening bolts from the fastening bracket on the fork head and hinge head
- 3 Remove the fastening bolt
- 4 Separate the linear actuator from the elements

Afterwards, you can prepare the MAGDRIVE™ for shipping (see section *Transport*, page 18) or store or dispose of it as described in the following sections.

Storage

For storage, pack the MAGDRIVE™ in its original packaging. Observe the following values when selecting a storage location:

- Ambient temperature: -10 °C to +40 °C
- Atmospheric humidity: up to 95%

Removing from service, dismantling and disposal

Disposal

The linear actuator is primarily made from recyclable materials. Specialized companies can separate the recyclable materials and therefore minimize the quantity of materials requiring disposal.

The linear actuator must be disposed of in a technically correct manner in accordance with local regulations. The plastic parts are marked with material specifications on the actual parts (except some of the smallest parts).

Please find dismantling instructions and shipping requirements in the relevant sections.

Appendix

8. Appendix

This chapter enables the user to find technical data, directories, diagrams and plans quickly.

Technical data

Equipment and operating data

The equipment and operating data can be found in the current datasheet.

- Datasheet for MAGDRIVE™ (L5321,2590E)
- Datasheet for MAGDRIVE™ accessories (L5321,2591E)
- Datenblatt für MAGDRIVE™ Wintergarten (L5321,2592E)

Current datasheets are available on the website (see www.magnetic.skf.com).

Please note: The linear actuator MAGDRIVE™ is designed for a service life of 10 years or 10,000 double strokes at a stroke length of 200 mm (with authorized usage).

Important: If the MAGDRIVE™ is operated beyond the defined operating values the operator must recalculate the life span from his own tests.

Ambient conditions

- Temperature range: +10 °C to +40 °C
- Atmospheric humidity: 5% to 85%

The linear actuator is suitable **for internal use only** and must not be exposed to weathering, strong UV radiation or corrosive or explosive atmospheric media, or other aggressive media.

Plans and diagrams

To view the plans and diagrams, please contact the manufacturer (see *Manufacturer Address*, page 6). Further information can be found in the datasheet. Current datasheets are available on the website (see www.magnetic.skf.com).

Appendix

Standards applied

- IEC 60601-1
- UL 60601-1

For further information, please contact the manufacturer (see *Manufacturer Address*, page 6).



Index

A	Ambient conditions	29
	Atmospheric humidity	29
B	Brake	14
C	Control unit	15
D	Drives	14
E	Electrical anti pinching protection	15
	Emergency lowering	15, 17
	End switch	14
	Equipment data	29
I	intermittent	9
	IPX4S	15
L	Linear unit	14
M	Manufacturer	6
	Motor casing	14
	Motor shaft	14
	Motor unit	14
O	Operating Authority	9
	Operating data	29
	Operating elements	15
	Operator	9
	Overall view	13
P	Patient lifters	17
	Power cable	14
	Processor	9
	Pulse generator	15
	Purpose	8
	Push tube	14
R	Reseller	9
S	Safety nut	14
	Spindle nut	14
T	Technician	9
	Temperature range	29
	Thermo-switch	14
	Third-party control units	20
	Tube casing	14
	Type plate	7
W	Worm gear	14